
Thermocouples

General Applications Flexible Extensions




Flexible extensions allow the disconnecting of thermocouples from a system without disturbing the remaining wiring.

Rapid Ship Sensors

Rapid Ship sensors come with standard female connector and a split lead termination.

Calibration	Lead Protection	Lead in.	Length (mm)	Part Number
J	Fiberglass with SS	48	(1219)	60XJBXE048A
	overbraid	96	(2438)	60XJBXE096A
	Fiberglass with SS	48	(1219)	60XJCXE048A
	hose	96	(2438)	60XJCXE096A
К	Fiberglass with SS	48	(1219)	60XKBXE048A
	overbraid	96	(2438)	60XKBXE096A
	Fiberglass with SS	48	(1219)	60XKCXE048A
	hose	96	(2438)	60XKCXE096A

Custom Ordering Information—Items in **Bolded Green Type** are preferred with shorter lead times.



6. Junction

X = Not applicable

7. Termination "A"

A = Standard, 2 ½ inch split leads

B = $2 \frac{1}{2}$ inch split leads with spade lugs

C = 2 ½ inch split leads with spade lugs and BX Connector

D = Standard male plug, quick disconnect

E = Standard female jack, quick disconnect

*F = Miniature male plug, quick disconnect

*G = Miniature female jack, quick disconnect

H = ¼ inch push-on connector

8-10. Lead Length (inches)

012, 024, 036, 040, 048, 060, 072, 079, 096 and 120

Available lengths: 006 to 360, over 360 consult factory

11. Termination "B"

A = Standard, 2 ½ inch split leads

B = 2½ inch split leads with #6 spade lugs

C = 2½ inch split leads with #6 spade lugs and BX connector

D = Standard male plug, quick disconnect

E = Standard female jack, quick disconnect

F = Miniature male plug, quick disconnect

G = Miniature female jack, quick disconnect

H = ¼ inch push-on connector

^{*} Not available with SS hose.